



PAVERSAVER UNI

Installation Directions

This specially formulated urethane rubber mat is a universal mat (22"x30") that can be trimmed to the size of almost any compactor plate. It is designed to help reduce damage to textured surface pavers, clay brick, natural stone and paving slabs. Since it absorbs some of the compactors energy, it will slightly reduce the forward speed. However, this special urethane mat minimizes the slow down normally caused by other protective mats. Protective mats may also require more passes during the compaction process to achieve complete paver lock-up.

Packing List

- Special Urethane Mat 22" x 30"
- Steel Mounting Cross Bar
- Mounting (2) Bolts, (4) Washers and (2) Locking Nuts
- 1/2" Plug Cutter bit for bolt holes in the Urethane Mat

Suggested Installation Tools:

- Two adjustable wrenches or sockets
- Electric drill
- 3/8" drill bit for steel
- Saws (hacksaw or jig saw)
- Permanent Marker
- Tape Measure

1. Check **PAVERSAVER UNI** kit for completeness.
2. Place the mounting cross bar over the bottom of the compactor plate so the top edge is approximately 1/4" back (down) from the leading edge of plate.
3. Align existing holes in plate with holes in mounting cross bar if possible, skip to step 11. If none exist, proceed to step 4.
4. Using a permanent marker, mark the bottom of your plate or the mounting cross bar where holes are to be drilled. Double-check hole positions to be drilled.
5. Using a 3/8" bit (made for drilling steel) or slightly larger, drill holes where marked.
6. Using mounting nuts, bolts and washers, test fit mounting cross bar to compactor plate before drilling urethane mat.
7. Mark mounting cross bar for cutting so ends do not go past the outside edges of the compactor plate.
8. Cut mounting cross bar and de-bur cut ends.
9. Using mounting cross bar as template, position it a minimum of 1" from the front edge of the mat and mark the hole for drilling.
10. Drill holes in urethane mat ONLY with provided IRWIN 1/2" plug cutter bit.
11. Mount urethane mat. Place bolt and washer into designated cross bar holes, then through the holes in the urethane mat and through plate holes. Place second set of washers on plate then fasten securely with supplied locking nuts.
12. Once mounted, mark the visible excess, dismount the mat and trim off the excess with a jig saw.

